


# User Manual


## Extra Long Metal Earphones

ADHF-027



Product overview .....	1
Use with Mobile device and newer PC.....	1
Use with TV, music keyboard and older PC.....	2
FAQ / Troubleshooting.....	4

# Product Overview




## Use with Mobile device and newer PC

---

**For smart phone, tablet and newer PC with single 3.5mm audio output jack**

Please make sure you remove the 4 to 3 pole converter and keep it safe for future use. Microphone will not function with converter installed.



# Use with TV, music keyboard and older PC

## For TV, music keyboard and older PC with two 3.5mm audio output jacks

Please make sure the 4 to 3 pole converter is CONNECTED to the earphone before use. Otherwise, you may experience muffled sound / low volume.

Check your TV's audio output options and connect according to the following.






	3.5mm/ Aux Out	3.5mm/ Aux In	RCA jacks labeled "AUDIO OUT"	Other RCA jacks (usually audio IN)	Big Phone Jack (6.35mm)
Jack Options					
Natively Supported?	✓	✗	✓✗	✗	✓✗
	<b>1</b>		<b>2</b>		<b>3</b>
			Need to buy converter separately		Need to buy converter separately

Fig 2-1

### 2.1 AUX Audio OUT




Fig 2-2

## 2.2 RCA Audio OUT (MUST be labeled Audio OUT!)




Fig 2-3

## 2.3 Big Phone Jack OUT (6.35mm)




Fig 2-4

**Note:** For TV with RCA or 6.35mm output, you need to order RCA to 3.5mm converter or 6.35mm to 3.5mm converter separately.

## FAQ / Troubleshooting

---

### No sound?

Refer to your TV's settings menu as settings differ between brands. After connecting your headphones to the appropriate AUDIO OUT jacks, please set your TV audio settings to "Headset" or "External Speakers". (Please refer to your TV's manual for clarification)

### Why I can't adjust the volume?

The volume control feature in wired headphones can only work with mobile device. Since these earphones are designed for TV, PC, or music keyboard use, there is no volume control.

If you want to adjust volume on your TV, there are two solutions: Solution A: Use the TV's remote control to adjust. There may be two different audio out settings for some TV's **AUDIO OUT** jacks; (**FIXED** or **VARIABLE**). Please change the audio setting to VARIABLE before you try to adjust volume.

Solution B: Purchase an inline volume controller to adjust the volume. For purchase details, just search "HF027 can't adjust volume" on support.avantree.com.

### Earbuds will not stay in my ears?

This is usually due to tension on the cable pulling the earbuds out. Please use the included CLIP to provide some slack between itself and the earbuds. (Clip to shirt, clothing etc.)

Note: Please do not clip it onto zipper or thick clothes.

### Cable is too short?

The coiled cord is about 5m / 15 feet long, but its effective working length is about 3m / 12 feet. Beyond that range the tension in the coil will be too strong. If you need a longer cable you will need to buy an extension cable separately.