![Avantree logo - For a Better Experience]

User Manual
True Wireless Earbuds

BTHS-TWS110

Product Overview

MFB

V- / ⏮

V+/ ⏭

L   R

How to wear?

Choose a snug-fitting pair of earbud tips - M works for most (Fig.1)

Insert earbud and adjust for secure fit (Fig.2)

(Fig.1)　　　　　(Fig.2)

Basic operation

| FUNCTION	OPERATION
Power On	Take out from charging case.OR short press ⊙ about 1s, LED light will illuminate **WHITE** about 1s.
Power Off	Put the earbuds into the charging case and they will power off and commence charging. Or long press ⊙ for about 5s, LED light will illuminate RED for about 2s, then turn off.
Pairing	Once powered on, they will connect with each other and **RIGHT** earbud will enter pairing emode,Then LED will flash **WHITE** and RED alternately.
Play / Pause	Short press ⊙ once
Volume Up / Down	Short press the ⬭ in the RIGHT / LEFT earbud
Previous / Next Track	Long press the ⬭ in the LEFT / RIGHT earbud
Answer / End A Call	Short press ⊙ once
Active Voice Assistant	Long press ⊙ about 1s then release

Connect to a mobile device

NOTE: Pair the RIGHT earbud with your mobile device ONLY.

First use >

1. First power on the RIGHT earbud; then the LEFT. They will connect to each other, and then the RIGHT earbud will enter pairing mode within 5-10s. Its LED light will flash **WHITE** and RED alternately.

flash **WHITE** and RED

2. Activate Bluetooth on your device. Search and select "Avantree TWS110" to connect. All the LEDs will turn off once connected. Now you can stream audio.

After first use (Reconnect), please >

1. Ensure the Bluetooth on your device is on.

2. Turn on the RIGHT earbud then the LEFT. Wait for 5~10 seconds, they will connect to the LAST PAIRED device.

Note: If it fails to reconnect, please click "Avantree TWS110" on your device to manually connect.

Connect to a NEW device>

1. Make sure the Bluetooth on previously connected device is off.

2. Follow the steps in the "First use" section to connect to a new device.

Mono earbud use >

The RIGHT earbud can be used individually for mono playback or calls. For volume down and previous track controls, please use your connected mobile device.

LED indicator status

EARBUDS STATUS	LED INDICATOR
Ready to pair	Flashes **WHITE** and RED alternately
Connected	Turns off
Not connected	Flashes **WHITE** once every 5s
Charging	Solid RED
Fully charged	Turns off

Charging

Charge the earbuds >

When you hear a voice prompt "battery low", please put the earbuds into the charging case to charge. It normally takes about 1 hour to fully charge.
During charging the LED on the earbud will illuminate red. When fully charged, the LED will turn off.

low battery

how to charge

charging

Charge the charging case >

A fully charged case can charge the earbuds 5-6 times, providing up to an additional 24 hours of play time.

When all the LEDs on the case flashes **white** rapidly about 5 times every 20 seconds, you should fully recharge the case (takes about 2.5 hours).
Please use a DC 5V / 0.5-2A USB wall charger / car charger / computer USB port with the included Micro USB cable to charge.

flash **WHITE** 5 times/20s

low battery

DC 5V / 0.5-2A

100%
75%
50%
25%

charing

While charging, the LED will flash white based on the battery level. When fully charged, all the LEDs will stay **white** until you pull off the charging cable.

Reset / clear pairing history

If the earbuds exhibit abnormal behavior, e.g. can't pair with device, please 'reset' your pairing history:

1. First put both earbuds back into the case:

2. Then take right earbud first then left earbud out.

3. Clearing right earbuds pairing history:

Long press the button till the LED light turned off. Release your finger, then long press again till it turned on and keep holding it till the light go off again. Now the right earbud's pairing history is cleared. Put it back into the case.

4. Clearing the left earbud pairing history:

Long press button, till the LED light turned off, release your fingers, now the left earbud's history is cleared. Put it back into the case

5. Now, take the right earbud first then the left earbud out of the case, wait for the left earbud's light turned off (The left earbud will emit white light for a quick second or two then will go dark. This means that the left earbud connected to the right earbud) and the right earbud flashing red and white alternatively (this indicates the right earbud is in pairing mode). Then find the Avantree TWS110 on your device, click on it to connect your device and the TWS110.